

# Bedienungsanleitung

## LED FLARES - 9 in 1 Notfallkreisel WF-1001PK / WF-2001PK

### Bedienungshinweise

Das Einschalten der LED Notfallkreisel erfolgt mittels des Ein-/Ausschalters an der Oberseite. Durch mehrfaches Betätigen des Schalters lassen sich insgesamt 9 Betriebsmodi einstellen. Ein Betätigen des Schalters für ca. 2 Sekunden schaltet das Gerät wieder aus.

### Batterieversion WF-2001PK

Der Flare wird mit einer handelsüblichen Lithium-Ionen Batterie betrieben (Modell CR123, 3V). Um die Batterie einzubauen oder auszutauschen, müssen die beiden Gehäuseschrauben entfernt und der Gehäusedeckel abgenommen werden. Beim Abnehmen des Gehäusedeckels keine Gewalt anwenden, um den Deckel nicht zu beschädigen. Falls sich der Deckel nicht per Hand abnehmen lässt, die 4 überstehenden Kunststoffnasen am Deckelrand mit einem Schraubendreher leicht anheben. Beim Einsetzen der Batterie auf die korrekte Polung achten. Beim Aufsetzen des Deckels darauf achten, dass die Gummidichtung nicht verkantet oder gequetscht

# Operating instructions

## LED FLARES - 9 in 1 emergency tool WF-1001PK/WF-2001PK

### Operating instructions

To turn on the flare press the ON/OFF switch on the upper side of the flare. The 9 different operating modes can be selected by repeatedly pressing the ON/OFF switch. Press the ON/OFF switch for approx. 2 seconds to turn off the flare.

### Battery type WF-2001PK

The flare is operated with a common lithium-ion battery (Modell CR123, 3V). To insert or exchange the battery, both screws need to be removed and the housing cover needs to be opened. Do not apply any force while opening the housing to avoid damaging the cover. If the cover cannot be removed smoothly, use a screwdriver to carefully lift the 4 plastic noses at the edge of the cover. When inserting the battery ensure the orientation is correct (+/-). Once the housing is closed, ensure the rubber gasket is not twisted or squeezed as this would have an adverse effect on the splash water density of the flare.

### Rechargeable type WF-1001PK

To charge the battery connect the charging unit provided to the bottom of the flare (ensure correct orientation (+/-)). The magnet of the flare will hold the

wird. Dies würde die Spritzwasserdichtigkeit negativ beeinflussen.

### Akkuverision WF-1001PK

Zum Laden des Akkus wird das Ladegerät an der Unterseite aufgesetzt (auf die korrekte Polung achten). Der Magnet des Flare hält das Ladegerät an seiner Position. Den USB Anschluss mit dem Stecker für 220V50/60Hz oder dem Einsatz für den Zigarettenanzünder im Kfz (12/24V) verbinden und diesen an die Stromquelle anschließen. Während des Ladevorgangs (ca. 6 Stunden nach Kompletentladung) leuchtet die LED des Ladegerätes rot. Nachdem der Akku aufgeladen ist schaltet die Elektronik auf Erhaltungsladung (die LED leuchtet grün).

### Sicherheitshinweis:

Die Flares enthalten Li-Ion Akkus. Beschädigte Akkus können überhitzen und einen Brand verursachen, daher müssen beschädigte Akkus/Flares umgehend ausgetauscht werden. Sofern eine Vorbeschädigung nicht ausgeschlossen werden kann, dürfen die Akkus nicht unbeaufsichtigt oder nur in nicht brennbarer Umgebung aufgeladen werden.

charging unit in its place. Then connect the USB cable either to the 220V50/60Hz power plug or to the insert of the vehicle cigarette lighter (12/24V) depending on which power source you will use for charging. While charging (takes approx. 6 hours if the battery was completely empty) the LED of the charging unit will glow in red color. Once the battery is completely charged the electronic will switch to conservation charging and the LED will glow green.

### Safety notice:

The flares contain Li-Ion batteries. Damaged batteries can overheat and cause a fire, therefore damaged batteries/flares must be replaced immediately. Batteries must not be charged unattended or only in a non-flammable environment if previous damages have not been excluded.



ATE20170153

WEEE-Reg  
36117605



# Dönges

WIR HABEN DAS ZEUG!

**DÖNGES GmbH & Co. KG**

Dönges-Straße 1  
D-42929 Wermelskirchen

Tel. +49 21 96 97 56-112

Mail: [feuerwehr@doenges-online.de](mailto:feuerwehr@doenges-online.de)

[www.doenges-online.de](http://www.doenges-online.de)